INSTRUCTIONS FOR YOUR

Hanging Kit



Note: Don't let things get all scratchy! Place your frame face down on a smooth, flat surface when assembling.

 With Frame face down. Remove the protective film from both sides of your Acrylic. In the following order, insert Acrylic or Glass, Artwork & Backing.

Retainer

Groove

Glass or Acrylic, Mat, Picture


and Backing

Retainer Clip

2. Install Retainer Clips by inserting the curved end, at an angle, into the Retainer Groove on the back of the frame. Press the Retainer Clip firmly into the Retainer Groove. Place Retainer Clips on all four sides using at least one Retainer Clip per side.

3. If Retainer Clips appear loose, add additional Backing such as cardboard, under the flat part of the Clip to secure your presentation. There must be enough material under the Clip to activate it fully. To remove Retainer Clips, carefully insert small, flat head screwdriver near the Retainer Groove, pull curved end out of the Groove with a sideways motion.

Do NOT pull straight out.



FRAME BACK

- Do NOT pail straight out.
- 4. Place the Hangers a third of the way from the top of the Frame and secure with Screws. Use the Retainer Groove to screw into, for proper placement. This should help ensure you don't screw through the Frame.
- 5. Thread the Hanging Wire through each Hanger, knot, and twist remaining wire tail to secure.
- 6. Hang your masterpiece and enjoy!